


REPORT OF ANALYSIS

For: (35432) OPEN FARM
Dog-OF Ancient Grains Turkey Kibble
11420FTGD

Analysis	Level Found		Reporting			Analyst-Date	Verified-Date
	As Received	Units	Limit	Method			
Sample ID: 11420FTGD-Micros	Lab Number: 13424975	Date Sampled: 2020-04-23					
Listeria	negative	org/125g	1	RapidChek/AOAC RI 020401	jbk4-2020/04/26	arj0-2020/04/27	
E. coli (generic)	n.d.	cfu/g	10	AOAC 991.14	clh4-2020/04/26	arj0-2020/04/27	
Salmonella	negative	org/375g	1	RapidChek/AOAC RI 030301; AFNOR SDI 34/01-04/10	jbk4-2020/04/26	arj0-2020/04/27	

All results are reported on an AS RECEIVED basis., n.d. = not detected , cfu = colony forming unit

For questions please contact:



Sara Sterkel-Colombo
Account Manager
scolombo@midwestlabs.com (402)590-2983

The result(s) issued on this report only reflect the analysis of the sample(s) submitted.

Our reports and letters are for the exclusive and confidential use of our clients and may not be reproduced in whole or in part, nor may any reference be made to the work, the results, or the company in any advertising, news release, or other public announcements without obtaining our prior written authorization.

REPORT OF ANALYSIS

For: (35432) OPEN FARM

Dog-OF Ancient Grains Turkey Kibble

11420FTGD

Detailed Method Description(s)

E. coli and Total Coliform using 3M Petrifilm

Sample analysis follows MWL MI 292 which is based on AOAC 991.14. A representative sample is obtained and added to phosphate buffer. Aliquots of the sample are withdrawn and placed on Petrifilm plates. The plates are incubated for 48 hours. After incubation, the plates are counted to determine the number of generic E. coli and total coliforms present. The color of the colony and the presence of gas differentiate a generic coliform from E. coli. The levels are reported as colony forming units (cfu).

Salmonella - Lateral Flow

Samples are analyzed following MWL MI 195 which is based on the RapidChek Select Salmonella User Guide. A representative sample is obtained and combined with a selective media and allowed to incubate. After incubation, a test strip is used for Salmonella determination. Results are reported as negative or presumptive positive.

Listeria Lateral Flow

Samples are analyzed following MWL MI 194 which is based on the RapidChek Listeria User Guide. A representative sample is obtained and combined with a selective growth media. It is incubated for 40-48 hours. After incubation, an aliquot is heated for 10 minutes, and a test strip for Listeria detection is used. Results are reported as negative or presumptive positive. This procedure does not speciate Listeria.

The result(s) issued on this report only reflect the analysis of the sample(s) submitted.

Our reports and letters are for the exclusive and confidential use of our clients and may not be reproduced in whole or in part, nor may any reference be made to the work, the results, or the company in any advertising, news release, or other public announcements without obtaining our prior written authorization.